



## Needle Valves

### Accessories

Achieve finer flow control with an adjustable needle valve.

Part No.	Description
13832-00	1/2" Needle Valve



## Solenoid Valves

### Accessories

Remotely start and stop with an in-line solenoid valve for the pump's air line.

Part No.	Description
13412-00-10	3/8" Ported Solenoid Valve, 110/50 or 120/60
13412-00-12	3/8" Ported Solenoid Valve, 12 VDC
13412-00-12	3/8" Ported Solenoid Valve, 12 VDC
13412-00-24	3/8" Ported Solenoid Valve, 24 VDC
13413-00-10	3/4" Ported Solenoid Valve, 110/50 or 120/60
13413-00-20	3/4" Ported Solenoid Valve, 220/50 or 240/60
13413-00-24	3/4" Ported Solenoid Valve, 24 VDC
13434-00	6' Cord with Din Plug